


# Compensated String Spacing Layout Tool



This is a layout tool for creating compensated string spacing when laying out a new nut. Slide the nut up or down the scale until the outsides of the nut line up with the two outside lines on the layout tool. Then mark the centers of your string slots and use the appropriate file to open the slot up to its final size.

